




OBD2 Port Plug In Solder Instructions



16 Pin OBDII Port Plug




16 Pin Cover
with 2 screws



Solder in 4 Volo wires to 4 pins

Tin the pins you will be soldering too.

Pin #4 (-) and Pin #16 (+)



Start by adding the rubber connector to the 4 volo wires. Give yourself 3/4" of each wire and take off 1/8" end of the wire. by melting the rubber coating and then tin the ends of the 4wires.